

PARTS LIST BY BAG				
<b>#</b>	<b>Resistors</b>	Identifier	<b>#</b>	<b>Misc Items</b>
2	33 ohm, 1/4w	Org-Org-Blk	1	10K pot
21	220 ohm, 1/4w	Red-Red-Brn	2	SPDT switches
4	270ohm, 1/2w	Red-Vio-Brn	1	SPST Switches
14	1K, 1/4w	Brn-Blk-Red	1	Pwr Jack
4	2.7K, 1/4w	Red-Vio-Red	1	Pwr Plug
2	3.9K, 1/4w	Org-White-Red	1	4pin USB Jack
1	4.7K, 1/4w	Yel-Vio-Red	1	RCA Phono Jack
8	10K, 1/4 watt	Brn-Blk-Org	2	1/4" jack
2	100K, 1/4 w	Brn-Blk-Yel	4	8pin DIN Jacks
2	1M, 1/4w	Brn-Blk-Grn	2	8pin DIN Plugs
			1	3.5mm jack
<b>#</b>	<b>Capacitors</b>	Identifier	1	Jumper Strip (10pins)
2	15pf	15	1	1uH RFC
1	.001uf	102	3	Beads
5	.01uf	103	1	DB25
9	.1uf	104	1	Knob
5	.33uf	334		
1	.47uf	474		
5	1 uf	105k		
2	10uf	106	<b>#</b>	<b>Hardware</b>
2	100uf	100uF	6	Alum Standoffs
			4	Rubber Feet
<b>#</b>	<b>Semiconductors</b>		12	#4-40 x 1/4" screws
2	Red LED		2	#4 nuts
2	Green LED		10	#4 Lock washers
5	1N4004 diode	(Black)	1	#4-40 x 3/8" screw
1	1N4148 diode	(Glass)	2	#10 Flat Washers
1	2N3904 Trans		1	#10-32 screw
1	PIC		1	#10 Lock washer
2	7805		1	#10-32 nut
1	PS2502-4		1	#10-32 wing nut
2	SN74HC594		2	Screws for DB25
1	Xtal		9	4-40 Black Screws
1	Digital Pot	MCP41010	9	4-40 Black Int LW
1	Relay		1	Heatsink
1	40pin IC socket		1	Fuse
3	16 pin IC socket		2	Fuse Holder Halves
<b>#</b>	<b>4Chan Parts</b>		<b>#</b>	<b>Transformers</b>
1	2N3904		4/8	Audio Xfmrs
4	1N4004 diode	(Black)		For 2/4 channels
1	1N4148TA diode	(Glass)		
1	PS2502-4			
1	16 pin IC socket			
4	270 ohm, 1/2 w resis	Red-Vio-Brn		
4	2.7K, 1/4w resistor	Red-Vio-Red		
1	4.7K, 1.4 w resistor	Yel-Vio-Red		
2	1M, 1/4w resistor	Brn-Blk-Grn		
2	Relays			
2	8pin DIN plugs			
1	Jumper Strip (8 Pins)			